



- NOTES**
- ① RETAIN THE SERVICE FOR THE FIRE ALARM, SECURITY SYSTEM AND BUILDING AUTOMATION SYSTEM REPRESENTATIVES TO REMOVE AND DISABLE ALL ASSOCIATED DEVICES FOR THE EXISTING SYSTEMS. DISCONNECT AND REMOVE ALL WIRING, CONDUIT AND WIRING FROM SWITCHBOARD ENCLOSURE. GENERATOR ENCLOSURE TO BE PREPARED FOR TRANSPORT AS INDICATED. SEAL OFF ALL OPENINGS WITH 1/2" MIN. THICK WATER TIGHT BARRIER. CAP ALL CONDUITS AND WIRING AND MAKE SAFE.
 - ② RETAINING THE SERVICE OF THE EXISTING GENERATOR SUPPLIER TO RUN AND TEST THE UNIT TO ENSURE PROPER FUNCTIONALITY OF THE UNIT. DISCONNECT AND REMOVE THE TRANSPORTATION MOUNT AND SECURE ALL EQUIPMENT IN THE GENERATOR ENCLOSURE READY FOR TRANSPORT
 - ③ DISCONNECT AND RELOCATE "GEN" PANELBOARD, 45KVA TRANSFORMER AND 60A DISCONNECT SWITCH TO BE REUSED WITH GENERATOR TO NEW LOCATION SITE. CAP WIRING AND CONDUIT IN SWITCHBOARD ENCLOSURE AND MAKE SAFE.
 - ④ DISCONNECT AND CAP EXISTING FEEDERS FROM GENERATOR IN TAB BOX ON 11TH FLOOR AS INDICATED. DISCONNECT FEEDERS FROM SWITCHBOARD ENCLOSURE. FEEDERS TO REMAIN ON 11TH FLOOR TO BE SUPPORTED BY THE GENERATOR SUPPLIER.

drawing no.	no. du dessin
-------------	---------------