

PART 1 **GENERAL**

1.1 **SECTION INCLUDES**

- .1 Service equipment and installation.

1.2 **RELATED SECTIONS**

- .1 Section 26 05 28 - Grounding - Secondary.
- .2 Section 26 05 31 - Splitters, Junction, Pull Boxes and Cabinets.
- .3 Section 26 24 16.01 - Panelboards Breaker Type.
- .4 Section 26 28 16.02 - Moulded Case Circuit Breakers.
- .5 Section 26 28 23 - Disconnect Switches - Fused and Non-Fused.

PART 2 **PRODUCTS**

2.1 **EQUIPMENT**

- .1 Fused disconnect switch: in accordance with Section 26 28 23 - Disconnect Switches - Fused and Non-Fused, rating as indicated.
- .2 Enclosed circuit breaker: in accordance with Section 26 28 16.02 - Moulded Case Circuit Breakers, rating as indicated.
- .3 Panelboard breaker type: in accordance with Section 26 24 16.01 - Panelboards Breaker Type Fusible type: in accordance with Section 26 28 16.02 - Panelboards Switch and Fuse Type, rating as indicated.
- .4 Cabinet type 'A' for utility revenue metering Junction box Pull box Splitter box: in accordance with Section 26 05 31 - Splitters, Junction, Pull Boxes and Cabinets, size as indicated.
- .5 Ground fault equipment: in accordance with Section 26 28 20 - Ground Fault Circuit Interrupters - Class "A".

PART 3 **EXECUTION**

3.1 **INSTALLATION**

- .1 Install service equipment.

- .2 Connect to incoming service.
- .3 Connect to outgoing load circuits.
- .4 Install ground fault equipment.
- .5 Make grounding connections in accordance with Section 26 05 28 - Grounding – Secondary.
- .6 Make provision for power supply authority's metering.

END OF SECTION