

Part 1 General

1.1 REFERENCES

- .1 American Society of Mechanical Engineers (ASME)
 - .1 ASME-04(2007), Boiler and Pressure Vessel Code.
- .2 ASTM International Inc.
 - .1 ASTM A47/A47M, Standard Specification for Ferritic Malleable Iron Castings.
 - .2 ASTM A536, Standard Specification for Ductile Iron Castings.
 - .3 ASTM B62, Standard Specification for Composition Bronze or Ounce Metal Castings.
- .3 Canadian Standards Association (CSA International)
 - .1 CSA B51, Boiler, Pressure Vessel, and Pressure Piping Code.
 - .2 CSA B51, Boiler, Pressure Vessel, and Pressure Piping Code, Supplement #1.

1.2 ACTION AND INFORMATIONAL SUBMITTALS

- .1 Provide submittals in accordance with Section 01 33 00 - Submittal Procedures.
- .2 Product Data:
 - .1 Provide manufacturer's printed product literature and datasheets for expansion tanks, air vents, separators, valves, and strainers and include product characteristics, performance criteria, physical size, finish and limitations.

1.3 CLOSEOUT SUBMITTALS

- .1 Submit maintenance and operation data in accordance with Section 01 78 00 - Closeout Submittals.

1.4 DELIVERY, STORAGE AND HANDLING

- .1 Deliver, store and handle in accordance with Section 01 61 00 - Common Product Requirements.
- .2 Deliver materials to site in original factory packaging, labelled with manufacturer's name, address.

Part 2 Products

2.1 CLOSED EXPANSION TANK

- .1 Horizontal expansion tank with threaded pipe connections existing to be revised.

2.2 AUTOMATIC AIR VENT

- .1 Standard float vent: brass body and NPS 1/8 connection and rated at 310 kPa working pressure.

2.3 AIR SEPARATOR - IN-LINE

- .1 Working pressure: 860 kPa.
- .2 Size: As shown on drawing.

2.4 PIPE LINE STRAINER

- .1 NPS 1/2 to 2: bronze body to ASTM B62, screwed connections, Y pattern.

Part 3 Execution

3.1 APPLICATION

- .1 Manufacturer's Instructions: comply with manufacturer's written recommendations, including product technical bulletins, handling, storage and installation instructions, and datasheets.

3.2 GENERAL

- .1 Run drain lines to terminate above nearest drain.
- .2 Maintain adequate clearance to permit service and maintenance.
- .3 Should deviations beyond allowable clearances arise, request and follow Departmental Representative's directive.
- .4 Check shop drawings for conformance of tappings for ancillaries and for equipment operating weights.

3.3 STRAINERS

- .1 Install in horizontal or down flow lines.
- .2 Ensure clearance for removal of basket.
- .3 Install ahead of each pump.
- .4 Install ahead of each automatic control valve larger than NPS 1 and as indicated.

3.4 AIR VENTS

- .1 Install at high points of systems.
- .2 Install gate valve on automatic air vent inlet.
- .3

3.5 PRESSURE SAFETY RELIEF VALVES

- .1 Run discharge pipe to terminate above nearest drain.

3.6 CLEANING

- .1 Clean in accordance with Section 01 74 11 – Cleaning.
 - .1 Remove surplus materials, excess materials, rubbish, tools and equipment.

END OF SECTION