

Part 1 General

1.1 SECTION INCLUDES

- .1 Service equipment and installation.

1.2 RELATED SECTIONS

- .1 Section 26 05 28 - Grounding - Secondary.
- .2 Section 26 05 31 - Splitters, Junction, Pull Boxes and Cabinets.
- .3 Section 26 28 16.02 - Moulded Case Circuit Breakers.
- .4 Section 26 28 23 - Disconnect Switches - Fused and Non-Fused.

Part 2 Products

2.1 EQUIPMENT

- .1 Fused disconnect switch: in accordance with Section 26 28 23 - Disconnect Switches - Fused and Non-Fused, ratings as indicated.
- .2 Panel board breaker type: in accordance with Section 26 28 16.02 – Molded Case Circuit Breaker Type, rating as indicated.
- .3 Cabinet type 'A' for utility revenue metering, junction box, pull box, and splitter box in accordance with Section 26 05 31 - Splitters, Junction, Pull Boxes and Cabinets, size as indicated.

Part 3 Execution

3.1 INSTALLATION

- .1 Install service equipment.
- .2 Connect to incoming service.
- .3 Connect to outgoing load circuits.
- .4 Make grounding connections in accordance with Section 26 05 28 - Grounding - Secondary.

END OF SECTION