




















<u>LEGEND</u>	
	COMBINATION STARTER
	PUMP CONNECTION
	FLOW METER
	OWS-OWNERS WORK STATION
	CONTROL PANEL
	ALARM HORN/SSTROBE
	ALARM BELL
	TRANSITION SUMP SENSOR
	RADAR LEVEL TRANSMITTER
	VACUUM GAUGE SWITCH
	OIL WATER SENSOR
D/W	DOUBLE WALL
A/G	ABOVE GROUND
	CURRENT TRANSDUCER
	TEMPERATURE SENSOR
	LEVEL TRANSMITTER
	PUMP
	SOLENOID VALVE
	RELAYS
	EXISTING LEAK SENSOR
	EXISTING BASEMENT ALARM BUZZER
~~~~~	DOUBLE WALL PIPE LEAK LEADER CABLE
-----	DOUBLE WALL LEAK LEADER CABLE

