

FIRE ALARM SCHEDULE											
FIRE ALARM ZONE No.	FIRE ALARM ZONE	FIRE ALARM ZONE DESCRIPTION AND ANNUNCIATOR FIRE ZONE LABEL	REGISTERED ON ANNUNCIATOR BY		REMARKS	FIRE ALARM ZONE No.	FIRE ALARM ZONE	FIRE ALARM ZONE DESCRIPTION AND ANNUNCIATOR FIRE ZONE LABEL	REGISTERED ON ANNUNCIATOR BY		REMARKS
			ALARM CIRCUIT	TROUBLE CIRCUIT					ALARM CIRCUIT	TROUBLE CIRCUIT	
1	F0-1	PARKING NORTH	X			63		SPARE			
2	F0-2	PARKING SOUTH	X			64		SPARE			
3	F1-1	MAIN FLOOR NORTH-EAST	X			65		FS-MAIN	X		SPRINKLER SYSTEM DEVICES IN PROGRESS
4	F1-2	MAIN FLOOR NORTH-WEST	X			66		SV-MAIN		X	
5	F1-3	MAIN FLOOR SOUTH	X			67		SV		X	
6	ATRIUM		X			68		SV		X	
7	F2-1	2ND FLOOR NORTH-EAST	X			69		SV		X	
8	F2-2	2ND FLOOR NORTH-WEST	X			70		SV		X	
9	F2-3	2ND FLOOR SOUTH	X			71		SV		X	
10	F3-1	3RD FLOOR NORTH-EAST	X			72		SV		X	
11	F3-2	3RD FLOOR NORTH-WEST	X			73		SV		X	
12	F3-3	3RD FLOOR SOUTH	X			74		FS MAIN FLOOR	X		
13	F4-1	4TH FLOOR NORTH-EAST	X			75		SV MAIN FLOOR		X	
14	F4-2	4TH FLOOR NORTH-WEST	X			76		FS MAIN FLOOR	X		
15	F5-1	5TH FLOOR NORTH-EAST	X			77		SV MAIN FLOOR		X	
16	F5-2	5TH FLOOR NORTH-WEST	X			78		FS MAIN FLOOR	X		
17	F5-2	5TH FLOOR NORTH-WEST	X			79		SV MAIN FLOOR		X	
18	ST-A	EXIT STAIR A	X			80		FS 2ND FLOOR	X		
19	ST-B	EXIT STAIR B	X			81		SV 2ND FLOOR		X	
20	ST-C	EXIT STAIR C	X			82		FS 2ND FLOOR	X		
21	ST-D	STAIR D	X			83		SV 2ND FLOOR		X	
22	ST-E	STAIR E	X			84		FS 2ND FLOOR	X		
23	ELEV-1	ELEVATOR 1 PIT & SHAFT	X			85		SV 2ND FLOOR		X	
24	ELEV-2	ELEVATOR 2 PIT & SHAFT	X			86		FS 3RD FLOOR	X		
25	ELEV-3	ELEVATOR 3 PIT & SHAFT	X			87		SV 3RD FLOOR		X	
26	ELEV-4	ELEVATOR 4 PIT & SHAFT	X			88		FS 3RD FLOOR	X		
27		ELEV. 1 & 2 MACHINE RM.	X			89		SV 3RD FLOOR		X	
28		ELEV. 3 MACHINE RM.	X			90		FS 3RD FLOOR	X		
29		MUA-01	X			91		SV 3RD FLOOR		X	
30		MUA-02	X			92		FS 4TH FLOOR	X		
31		MUA-03	X			93		SV 4TH FLOOR		X	
32		FPB-05	X			94		FS 4TH FLOOR	X		
33		FPB-13	X			95		SV 4TH FLOOR		X	
34		SPARE				96		FS 5TH FLOOR	X		
35		SPARE				97		SV 5TH FLOOR		X	
36		GENERATOR SET RUNNING		X		98		FS PENTHOUSE	X		
37		GENERATOR SET TROUBLE		X		99		SV PENTHOUSE		X	
38		SPARE				100		FS 2ND FLOOR WINDOWS	X		
39		SPARE				101		SV 2ND FLOOR WINDOWS		X	
40		SPARE				102		FS 3RD FLOOR WINDOWS	X		
41		SPARE				103		SV 3RD FLOOR WINDOWS		X	
42		SPARE				104		FS 4TH FLOOR WINDOWS	X		
43		SPARE				105		SV 4TH FLOOR WINDOWS		X	
44		SPARE				106		FS 5TH FLOOR WINDOWS	X		
45		SPARE				107		SV 5TH FLOOR WINDOWS		X	
46		FIRE PUMP RUNNING		X		107		SV 5TH FLOOR WINDOWS			
47		FIRE PUMP LOSS OF PHASE		X							
48		FIRE PUMP PHASE REVERSAL		X							
49		FIRE PUMP CONTROLLER ON ALTERNATE POWER		X							
50		FIRE PUMP ALTERNATE SOURCE BREAKER OPEN		X							
51		FIRE PUMP CONTROLLER TROUBLE		X							
52											
53											
54											
55											
56											
57											
58											
59											
60											
61											
62											

