


1 - ANCHOR POINT FOR ATTACHMENT WHEN TRANSITTING LADDERS

2 - ANCHOR POINT FOR TRANSITTING OR WORKING ATOP FUNNEL OR MAINTENANCE OF WHTOD FLOODLIGHT

AFT MAST
664-16-3
ELECTRONIC GOSA0800.pdf
MARKED UP