

---

**CLARIFICATION:**

**Question 1.:** Vertical fender plan section; on this plan view it shows a nut on backside of existing steel bracket inside dish of sheet pile wall.

- a) Is this a existing nut welded to backside of bracket?
- b) Are brackets welded into place?

If they are welded into place there is very minimal space approx. 1 ½" gap to 2" along side of timber to install this nut if it's not a pre welded nut.

**Answer 1.:** According to historical documents the nuts are not welded onto the back of the brackets and the brackets are welded to the sheet pile .