

**Correctional Service Canada
Technical Services Branch
Electronics Systems**

**Issue 1
October 24, 2014**

**STATEMENT
OF
TECHNICAL REQUIREMENTS

UPGRADE

of

INTERNAL (SIDS) CCTV SYSTEMS

at

MILLHAVEN INSTITUTION**

**Appendix E

Camera Assignment Tables**

This Statement of Technical Requirements is approved by the Correctional Service of Canada for the upgrade of the existing Hybrid CCTV System at Millhaven Institution.

Camera #	Map	Building	Room (FOV)	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-1	421-key	MHT	PFVs	N	n/a	Camera Type #6	MHT-169	1	parapet mount
C-2	421-key	MHN	N Tower (SIDS)	E	Panasonic WV-CW864	Camera Type #7	MHN-B	3	On top of Tower roof of N building
C-3	421-key	MHT2	2 Tower (yard)	N	n/a	Camera Type #7	MHT2	Perimeter	under observation deck lift accessible
C-4	421-key	MHS	Main yard	N	n/a	Camera Type #6	MHS-208	4.2	Altron SBI-RM/D parapet mount
C-5	421-key	MHS	Main yard	N	n/a	Camera Type #7	MHS-208	4.2	Altron SBI-RM/D parapet mount
C-6	421-key	MHS	Main yard	N	n/a	Camera Type #6	MHS-208	4.2	Altron SBI-RM/D parapet mount
C-7	421-key	MHTB	Main yard	N	n/a	Camera Type #6	MHTB-101	2.1	under observation deck lift accessible
C-8	421-key	MHTB	A Yard	N	n/a	Camera Type #6	MHTB-101	2.1	under observation deck lift accessible
C-9	421-key	MHTB	A Yard	N	n/a	Camera Type #7	MHTB-101	2.1	under observation deck lift accessible
C-10	421-key	MHTB	A Yard	N	n/a	Camera Type #6	MHTB-101	2.1	under observation deck lift accessible
C-11	421-key	MHS	A Yard	N	n/a	Camera Type #7	MHS-208	4.2	Altron SBI-RM/D parapet mount
C-12	421-key	MHS	A Yard	N	n/a	Camera Type #6	MHS-208	4.2	Pedestal mpunt on roof top
C-13	421-key	Tower	A Yard	E	Panasonic WV-CS854	Camera Type #7	MHUMA-212	5.1	Altron AW1545/TD 12M
C-14	421-key	Tower	New Unit	E	Panasonic WV-CS854	Camera Type #7	MHUMA-212	5.1	Altron AW1545/TD 12M
C-15	421-key	MHU	loading dock	E	n/a	Camera Type #6	MHU-Kitchen	8.1	wall mount (under overhang)
C-16	421-key	MHU	loading dock	E	n/a	Camera Type #6	MHU-Kitchen	8.1	wall mount (under overhang)
C-17	421-key	MHU	loading dock	E	Panasonic WV-BP510	Camera Type #6	MHU-202	8	wall mount (under overhang)
C-18	421-key	MHU	loading dock	E	Panasonic WV-BP510	Camera Type #6	MHU-202	8	wall mount (under overhang)
C-19	421-key	MHW	Sally Port	N	n/a	Camera Type #7	MHW-101	2.2.1	Altron AW1545/TD 12M
C-20	421-key	MHT3	3 Tower (SIDS JR)	E	Panasonic WV-CW864	Camera Type #7	MHT3	2.2	replace existing camera

Camera #	Map	Building	Room (FOV)	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-21	MHA-1	MHA	102	N	n/a	Camera Type #1	MHD-B	5	wall mount - centered
C-22	MHA-1	MHA	103	E	AXIS 211	Camera Type #3	MHD-B	5	wall mount - centered
C-23	MHA-1	MHA	104	E	AXIS 211	Camera Type #1	MHD-B	5	wall mount - centered
C-24	MHA-1	MHA	104	N	n/a	Camera Type #1	MHD-B	5	wall mount - centered
C-25	MHA-1	MHA	ST-01	E	AXIS 211	Camera Type #2	MHD-B	5	modify existing bracket
C-26	MHA-1	MHA	ST-02	N	n/a	Camera Type #2	MHD-B	5	provide new bracket
C-27	MHA-1	MHA	ST-03	E	AXIS 211	Camera Type #2	MHD-B	5	modify existing bracket
C-28	MHA-2	MHA	201	E	AXIS 211	Camera Type #1	MHD-B	5	wall mount - centered
C-29	MHA-2	MHA	202	N	n/a	Camera Type #3	MHD-B	5	wall mount - centered
C-30	MHA-2	MHA	205	N	n/a	Camera Type #3	MHD-B	5	wall mount - centered
C-31	MHA-2	MHA	206	N	n/a	Camera Type #1	MHD-B	5	wall mount - centered
C-32	MHA-2	MHA	ST-01	E	AXIS 211	Camera Type #2	MHD-B	5	replace existing enclosure
C-33	MHA-2	MHA	ST-02	E	AXIS 211	Camera Type #2	MHD-B	5	replace existing enclosure
C-34	MHA-2	MHA	ST-03	E	AXIS 211	Camera Type #2	MHD-B	5	replace existing enclosure
C-35	MHA-B	MHA	B02	E	Panasonic WV-CP470	Camera Type #1	MHD-B	5	modify existing bracket
C-36	MHA-B	MHA	B03	E	Panasonic WV-CP470	Camera Type #1	MHD-B	5	modify existing bracket
Camera #	Map	Building	Room (FOV)	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-37	MHB-1	MHB	134	N	n/a	Camera Type #1	MHD-B	5	wall mount - centered
C-38	MHB-1	MHB	131	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered
C-39	MHB-2	MHB	201	N	n/a	Camera Type #1	MHD-B	5	corner mounted/ceiling
C-40	MHB-2	MHB	231	N	n/a	Camera Type #1	MHD-B	5	wall mount - centered
C-41	MHB-2	MHB	232	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered
C-42	MHB-2	MHB	232	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-43	MHC-1	MHC	134	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered
C-44	MHC-2	MHC	234	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-45	MHD-1	MHD	101	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered
C-46	MHD-2	MHD	233	N	n/a	Camera Type #2	MHD-B	5	wall mount - centered

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-47	MHE-1	MHE	102	E	AXIS 211	Camera Type #3	MHH-B	6	wall mount - centered
C-48	MHE-1	MHE	103	N	n/a	Camera Type #1	MHH-B	6	wall mount - centered
C-49	MHE-1	MHE	103	N	n/a	Camera Type #1	MHH-B	6	ceiling mount - centered
C-50	MHE-1	MHE	104	N	n/a	Camera Type #1	MHH-B	6	ceiling mount - centered
C-51	MHE-1	MHE	ST-01	E	AXIS 211	Camera Type #2	MHH-B	6	modify existing bracket
C-52	MHE-1	MHE	ST-02	N	n/a	Camera Type #2	MHH-B	6	provide new bracket
C-53	MHE-1	MHE	ST-03	E	AXIS 211	Camera Type #2	MHH-B	6	modify existing bracket
C-54	MHE-2	MHE	201	E	AXIS 211	Camera Type #3	MHH-B	6	wall mount - centered
C-55	MHE-2	MHE	204	E	AXIS 211	Camera Type #3	MHH-B	6	wall mount - centered
C-56	MHE-2	MHE	207	E	AXIS 211	Camera Type #1	MHH-B	6	wall mount - centered
C-57	MHE-2	MHE	ST-01	E	AXIS 211	Camera Type #2	MHH-B	6	modify existing bracket
C-58	MHE-2	MHE	ST-02	E	AXIS 211	Camera Type #2	MHH-B	6	modify existing bracket
C-59	MHE-2	MHE	ST-03	E	AXIS 211	Camera Type #2	MHH-B	6	modify existing bracket
C-60	MHE-B	MHE	B02	E	Panasonic WV-CP470	Camera Type #1	MHH-B	6	modify existing bracket
C-61	MHE-B	MHE	B03	E	Panasonic WV-CP470	Camera Type #1	MHH-B	6	modify existing bracket
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-62	MHF-1	MHF	134	N	n/a	Camera Type #2	MHH-B	6	wall mount - centered
C-63	MHF-2	MHF	201	N	n/a	Camera Type #5	MHH-B	6	wall mount - centered
C-64	MHF-2	MHF	232	N	n/a	Camera Type #2	MHH-B	6	wall mount - centered
C-65	MHF-2	MHF	232	N	n/a	Camera Type #2	MHH-B	6	wall mount - centered
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-66	MHG-1	MHG	131	N	n/a	Camera Type #3	MHH-B	6	ceiling mount
C-67	MHG-2	MHG	231	N	n/a	Camera Type #1	MHH-B	6	Ceiling mount
C-68	MHG-2	MHG	234	N	n/a	Camera Type #2	MHH-B	6	wall mount - centered
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-69	MHH-1	MHH	101	N	n/a	Camera Type #2	MHH-B	6	wall mount - centered
C-70	MHH-2	MHH	233	N	n/a	Camera Type #2	MHH-B	6	wall mount - centered

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-71	MHJ-1	MHJ	102	N	n/a	Camera Type #3	MHM-B	7	wall mount - centered
C-72	MHJ-1	MHJ	103	E	AXIS 211	Camera Type #1	MHM-B	7	wall mount - centered
C-73	MHJ-1	MHJ	103	N	n/a	Camera Type #1	MHM-B	7	wall mount - centered
C-74	MHJ-1	MHJ	104	N	n/a	Camera Type #3	MHM-B	7	wall mount - centered
C-75	MHJ-1	MHJ	ST-01	E	AXIS 211	Camera Type #2	MHM-B	7	modify existing bracket
C-76	MHJ-1	MHJ	ST-02	N	n/a	Camera Type #2	MHM-B	7	provide new bracket
C-77	MHJ-1	MHJ	ST-03	E	AXIS 211	Camera Type #2	MHM-B	7	modify existing bracket
C-78	MHJ-2	MHJ	201	E	AXIS 211	Camera Type #3	MHM-B	7	wall mount - centered
C-79	MHJ-2	MHJ	202	E	AXIS 211	Camera Type #1	MHM-B	7	wall mount - centered
C-80	MHJ-2	MHJ	203	E	AXIS 211	Camera Type #3	MHM-B	7	wall mount - centered
C-81	MHJ-2	MHJ	ST-01	E	AXIS 211	Camera Type #2	MHM-B	7	modify existing bracket
C-82	MHJ-2	MHJ	ST-02	E	AXIS 211	Camera Type #2	MHM-B	7	provide new bracket
C-83	MHJ-2	MHJ	ST-03	E	AXIS 211	Camera Type #2	MHM-B	7	modify existing bracket
C-84	MHJ-B	MHJ	B02	E	Panasonic WV-CP470	Camera Type #1	MHM-B	7	modify existing bracket
C-85	MHJ-B	MHJ	B03	E	Panasonic WV-CP470	Camera Type #1	MHM-B	7	modify existing bracket
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-86	MHK-1	MHK	134	N	n/a	Camera Type #2	MHM-B	7	wall mount - centered
C-87	MHK-2	MHK	204	N	n/a	Camera Type #5	MHM-B	7	corner mount
C-88	MHK-2	MHK	232	N	n/a	Camera Type #2	MHM-B	7	wall mount - centered
C-89	MHK-2	MHK	232	N	n/a	Camera Type #2	MHM-B	7	wall mount - centered
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-90	MHL-1	MHL	134	E	AXIS 211	Camera Type #2	MHM-B	7	wall mount - centered
C-91	MHL-2	MHL	234	E	AXIS 211	Camera Type #2	MHM-B	7	wall mount - centered
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-92	MHM-1	MHM	101C	E	AXIS 211	Camera Type #2	MHM-B	7	wall (prefered) or ceiling mount
C-93	MHM-2	MHM	233	E	AXIS 211	Camera Type #2	MHM-B	7	wall mount - centered

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-94	MHN-1	MHN	102	E	AXIS 225FD	Camera Type #1	MHN-B	3	45 degree bracket
C-95	MHN-1	MHN	102	E	AXIS 225FD	Camera Type #1	MHN-B	3	45 degree bracket
C-96	MHN-1	MHN	102	E	AXIS 225FD	Camera Type #1	MHN-B	3	45 degree bracket
C-97	MHN-1	MHN	102	E	AXIS 225FD	Camera Type #1	MHN-B	3	45 degree bracket
C-98	MHN-1	MHN	102	E	AXIS 225FD	Camera Type #1	MHN-B	3	45 degree bracket
C-99	MHN-1	MHN	102	E	AXIS 225FD	Camera Type #1	MHN-B	3	45 degree bracket
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-100	MHN-B	MHN	B02	E	Panasonic WV-CP470	Camera Type #1	MHN-B	3	modify existing bracket
C-101	MHN-B	MHN	B05	E	Panasonic WV-CP470	Camera Type #1	MHN-B	3	modify existing bracket
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-102	MHP-1	MHP	101	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
C-103	MHP-1	MHP	101	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
C-104	MHP-1	MHP	101	N	n/a	Camera Type #2	MHU-202	8	ceiling mount
C-105	MHP-1	MHP	101	N	n/a	Camera Type #2	MHU-202	8	ceiling mount
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-106	MHQ-1	MHQ	101	N	n/a	Camera Type #2	MHT-169	1	ceiling mount
C-107	MHQ-1	MHQ	101	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-108	MHR-1	MHR	201	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
C-109	MHR-1	MHR	201	N	n/a	Camera Type #2	MHS-B	4	ceiling mount
C-110	MHR-1	MHR	201	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
C-111	MHR-1	MHR	201	N	n/a	Camera Type #2	MHS-B	4	ceiling mount
C-112	MHR-1	MHR	101	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
C-113	MHR-1	MHR	101	N	n/a	Camera Type #2	MHS-B	4	ceiling mount
C-114	MHR-1	MHR	101	N	n/a	Camera Type #2	MHN-B	3	ceiling mount
C-115	MHR-1	MHR	101	N	n/a	Camera Type #2	MHS-B	4	ceiling mount

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-116	MHS-1	MHS	SEG yard	E	AXIS 211	Camera Type #1	MHS-B-W	4.1	corner mount - existing location
C-117	MHS-1	MHS	SEG yard	E	AXIS 211	Camera Type #1	MHS-B-W	4.1	corner mount - existing location
C-118	MHS-1	MHS	SEG yard	N	n/a	Camera Type #1	MHS-B-W	4.1	corner mount
C-119	MHS-1	MHS	SEG yard	N	n/a	Camera Type #1	MHS-B-W	4.1	corner mount
C-120	MHS-1	MHS	135	E		Camera Type #1	MHS-B-W	4.1	wall mount - centered
C-121	MHS-1	MHS	135	E		Camera Type #1	MHS-B-W	4.1	wall mount - centered
C-122	MHS-1	MHS	142	E		Camera Type #1	MHS-B-W	4.1	wall mount - centered
C-123	MHS-1	MHS	142	E		Camera Type #1	MHS-B-W	4.1	wall mount - centered
C-124	MHS-1	MHS	S04	E		Camera Type #5	MHS-B-W	4.1	corner mount - existing location
C-125	MHS-1	MHS	S03	E		Camera Type #5	MHS-B-W	4.1	corner mount - existing location
C-126	MHS-1	MHS	S02	E		Camera Type #5	MHS-B-W	4.1	corner mount - existing location
C-127	MHS-1	MHS	S01	E		Camera Type #5	MHS-B-W	4.1	corner mount - existing location
C-128	MHS-1	MHS	130	N	n/a	Camera Type #1	MHS-B-W	4.1	wall mount - centered
C-129	MHS-1	MHS	128	E		Camera Type #2	MHS-B-W	4	wall mount - centered
C-130	MHS-1	MHS	121	E		Camera Type #2	MHS-B-W	4	wall mount - centered
C-131	MHS-1	MHS	148	N	n/a	Camera Type #2	MHS-B-W	4	wall mount - centered
C-132	MHS-1	MHS	148	N	n/a	Camera Type #2	MHS-B-W	4	wall mount - centered
C-133	MHS-1	MHS	107	E	Panasonic WV-CP470	Camera Type #1	MHS-2	4.2	wall mount
C-134	MHS-1	MHS	107	E	Panasonic WV-CP470	Camera Type #1	MHS-2	4.2	wall mount
C-135	MHS-1	MHS	118	N	n/a	Camera Type #2	MHS-2	4.2	wall mount
C-136	MHS-1	MHS	118	E	Panasonnic WV-CS404	Camera Type #7	MHS-2	4.2	ceiling mount
C-137	MHS-1	MHS	118	E	Panasonic WV-CP470	Camera Type #2	MHS-2	4.2	relocate to W corner/ceiling mount
C-138	MHS-1	MHS	118	E	Panasonic WV-CP470	Camera Type #2	MHS-2	4.2	relocate to N corner/ceiling mount
C-139	MHS-1	MHS	118	N	n/a	Camera Type #7	MHS-2	4.2	ceiling mount
C-140	MHS-1	MHS	115	E	Panasonic WV-CP474	Camera Type #1	MHS-2	4.2	wall mount
C-141	MHS-1	MHS	115	E	Panasonic WV-CP474	Camera Type #1	MHS-2	4.2	wall mount
C-142	MHS-1	MHS	118	N	n/a	Camera Type #2	MHS-2	4.2	relocate to E corner/ceiling mount
C-143	MHS-1	MHS	113	E	AXIS 225FD	Camera Type #1	MHS-2	4.2	wall mount
C-144	MHS-1	MHS	102	E	Panasonic WV-CP474	Camera Type #1	MHS-B	4.2	wall mount
C-145	MHS-1	MHS	102	E	Panasonic WV-CP484	Camera Type #2	MHS-B	4.2	wall mount
C-146	MHS-1	MHS	101	E	Panasonic WV-CP484	Camera Type #2	MHS-B	4	wall mount

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-147	MHS-1	MHS	158	E	Panasonic WV-CP470	Camera Type #1	MHS-B-E	4	corner mount - existing location
C-148	MHS-1	MHS	158	E	Panasonic WV-CP470	Camera Type #1	MHS-B-E	4	corner mount - existing location
C-149	MHS-1	MHS	182	E	Panasonic WV-CP470	Camera Type #1	MHS-B-E	4	wall mount
C-150	MHS-1	MHS	H03	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount
C-151	MHS-1	MHS	H04	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount
C-152	MHS-1	MHS	H07	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-153	MHS-1	MHS	H08	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-154	MHS-1	MHS	H09	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-155	MHS-1	MHS	H10	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-156	MHS-1	MHS	H11	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-157	MHS-1	MHS	H12	E	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-158	MHS-1	MHS	183	N	n/a	Camera Type #5	MHS-B-E	4	corner mount
C-159	MHS-1	MHS	181	N	n/a	Camera Type #5	MHS-B-E	4	corner mount
C-160	MHS-1	MHS	182	N	n/a	Camera Type #1	MHS-B-E	4	wall mount
C-161	MHS-1	MHS	182	N	n/a	Camera Type #1	MHS-B-E	4	wall mount
C-162	MHS-1	MHS	H13	N	n/a	Camera Type #5	MHS-B-E	4	corner mount
C-163	MHS-1	MHS	H14	N	n/a	Camera Type #5	MHS-B-E	4	corner mount
C-164	MHS-1	MHS	H15	N	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-165	MHS-1	MHS	H16	N	Panasonic WV-CP470	Camera Type #5	MHS-B-E	4	corner mount - existing location
C-166	MHS-1	MHS	193	E	Panasonic WV-CP484	Camera Type #2	MHS-B-E	4	wall mount
C-167	MHS-1	MHS	193	E	n/a	Camera Type #2	MHS-B-E	4	wall mount
C-168	MHS-1	MHS	193	E	n/a	Camera Type #2	MHS-B-E	4	wall mount
C-169	MHS-1	MHS	193	N	Panasonic WV-CP484	Camera Type #1	MHS-B-E	4	wall mount
C-170	MHS-1	MHS	195	N	n/a	Camera Type #1	MHS-B-E	4	wall mount
C-171	MHS-1	MHS	195	N	n/a	Camera Type #1	MHS-B-E	4	wall mount

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location	node #	mounting instructions
C-172	MHT-1	MHT	125	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-173	MHT-1	MHT	125	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-174	MHT-1	MHT	125	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-175	MHT-1	MHT	124	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-176	MHT-1	MHT	124	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-177	MHT-1	MHT	124	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-178	MHT-1	MHT	128	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall or ceiling (prefered) mount
C-179	MHT-1	MHT	126	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount - above door
C-180	MHT-1	MHT	123	E	Panasonic WV-CS854	Camera Type #7	MHT-169	1	Ceiling mounted
C-181	MHT-1	MHT	123	E	Panasonic WV-CS854	Camera Type #7	MHT-169	1	Ceiling mounted
C-182	MHT-1	MHT	123	E	Panasonic WV-CS854	Camera Type #7	MHT-169	1	Ceiling mounted
C-183	MHT-1	MHT	116	E	Panasonic WV-CW474	Camera Type #1	MHT-169	1	wall mount
C-184	MHT-1	MHT	102	N	n/a	Camera Type #3	MHT-169	1	wall mount
C-185	MHT-1	MHT	102	E	Panasonic WV-CP470	Camera Type #1	MHT-169	1	Ceiling mounted
C-186	MHT-1	MHT	142	E	Panasonic WV-CP470	Camera Type #1	MHT-169	1	Ceiling mounted - corridor mode

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location		mounting instructions
C-187	MHU-1	MHU	1159	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-188	MHU-1	MHU	1159	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-189	MHU-1	MHU	1158	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-190	MHU-1	MHU	1158	N	n/a	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-191	MHU-1	MHU	1160	N	Panasonic WV-CP470	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-192	MHU-1	MHU	1165	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-193	MHU-1	MHU	1165	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-194	MHU-1	MHU	1176	N	n/a	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-195	MHU-1	MHU	1168	N	n/a	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-196	MHU-1	MHU	1173	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-197	MHU-1	MHU	1173	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-198	MHU-1	MHU	1177	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-199	MHU-1	MHU	1177	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-200	MHU-1	MHU	1183	N	n/a	Camera Type #1	MHU-2-202	8	ceiling mount extension
C-201	MHU-1	MHU	1183	N	n/a	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-202	MHU-1	MHU	1183	N	n/a	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-203	MHU-1	MHU	1139	N	n/a	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-204	MHU-1	MHU	1139	N	n/a	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-205	MHU-1	MHU	1113	N	n/a	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-206	MHU-1	MHU	1113	N	n/a	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-207	MHU-1	MHU	1119	N	n/a	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-208	MHU-1	MHU	1119	N	n/a	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-209	MHU-1	MHU	1087	N	n/a	Camera Type #1	MHU-2-202	8	suspend from ceiling
C-210	MHU-1	MHU	1006	N	n/a	Camera Type #2	MHU-2-202	8	wall or ceiling mount
C-211	MHU-1	MHU	1013	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	ceiling mount
C-212	MHU-1	MHU	1013	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	ceiling mount
C-213	MHU-1	MHU	1014	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	ceiling mount
C-214	MHU-1	MHU	1014	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	ceiling mount
C-215	MHU-1	MHU	1015	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-216	MHU-1	MHU	1015	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-217	MHU-1	MHU	1012	N	n/a	Camera Type #2	MHU-2-202	8	wall mount
C-218	MHU-1	MHU	1016	N	n/a	Camera Type #2	MHU-2-202	8	wall mount

Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location		mounting instructions
C-219	MHU-1	MHU	1023	N	n/a	Camera Type #2	MHU-2-202	8	wall mount
C-220	MHU-1	MHU	1193	E	Panasonic WV-CP470	Camera Type #1	MHU-2-202	8	wall or ceiling mount
C-221	MHU-1	MHU	1058	N	n/a	Camera Type #3	MHU-2-202	8	ceiling mount
C-222	MHU-1	MHU	1054A	E	Panasonic WV-CP470	Camera Type #5	MHU-2-202	8	corner mount
C-223	MHU-1	MHU	1054B	N	n/a	Camera Type #5	MHU-2-202	8	corner mount
C-224	MHU-1	MHU	1054C	E	Panasonic WV-CP470	Camera Type #5	MHU-2-202	8	corner mount
C-225	MHU-1	MHU	1001	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-226	MHU-1	MHU	1001	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-227	MHU-1	MHU	1141	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-228	MHU-1	MHU	1141	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-229	MHU-1	MHU	1086	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-230	MHU-1	MHU	1086	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-231	MHU-1	MHU	1186	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-232	MHU-1	MHU	1186	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-233	MHU-1	MHU	1045	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
C-234	MHU-1	MHU	1045	N	n/a	Camera Type #2	MHU-2-202	8	ceiling mount
Camera #	Map	Building	Room	(N)ew/(E)xisting	Existing camera	replacement model	node location		mounting instructions
C-235	MHX-1	MHX	102	E	WV-BP510	Camera Type #3	Main Tunnel	10	wall mount
C-236	MHX-1	MHX	101	E	360	Camera Type #4	Main Tunnel	10	ceiling mount