

E ELEVATION LOOKING TO PORT



ELEVATION @ C OF SHAFT & 33 6"/8" LOOKING OUTBOARD



SECTION AT FR 84 LOOKING FWD.

VALVE	SHAFT	SIZE	DESCRIPTION	FUNCTION	MATERIAL	REMARKS	FIG. OR
S.A. 1	S	2"	125#. GATE VALVE	AIR RECEIVER, S.S.H.P.	S.S. ASTM A 276 TYPE 304	250 PSI	29 -01
2	S	2"	SCREW DOWN STOP CHECK VALVE	MAIN PUR. STARTING AIR	"	"	4
3	S	1½"	"	EMERGENCY GENERATOR STARTING AIR	"	250 PSI W.P.	29-09
4	S	1½"	"	REDUCING STATION	"	"	29-09
5	S	1½"	"	DISTRIBUTION MANIFOLD	"	"	29-09
6	S	¾"	"	"	"	"	29-09
7	S	¾"	"	AUX. SERVICES, H.P.T.	"	"	29-09
8	S	¾"	"	CONTROLLER PILOTS'Y	"	"	29-09
9	S	¾"	"	DIESEL START SOLENOID CONTROL	"	"	29-13
10	S	¾"	"	ENGINE AIR MOTORS	"	"	4
11							
12	S	1¼"	300#. GLOBE VALVE	SERVICE DISPATCHED STARTING AIR	S.S. ASTM A 276 TYPE 304	250 PSI W.P.	29-09
13	S	¾"	ANGLE VALVE FOR P.O.V.	MOTOR SHAFT GENERATOR CONTROL	STEEL	"	29-09
14	S	¾"	GLOBE " "	MAIN ENGINE START VALVE	"	"	29-09
15	S	¾"	" "				29-09
16	S	¾"	GATE VALVE	CONTROL AIR			29-09
17	S	¾"	LIFT CHECK VALVE	MAIN ENGINE STARTING AIR	CAST STEEL, FLG'D 300#		29-09
18	S	¾"	" "	COMPRESSOR DELIVERY	" " "		29-09
19	S	¾"	" "	AIR TO CONTROL AIR SUPPLY			29-09
20	S	¾"	GLOBE "	WHEELHOUSE	BRONZE	150 PSI W.P.	29-09
21	S	¾"	" STRAINER	MAIN BILGE STARTING AIR	CAST STEEL, FLG'D 300#		29-09
22	S	¾"	" "	MAIN BILGE STARTING AIR	" " "		29-09
23	S	¾"	SCREW DOWN STOP CHECK VALVE	EMERGENCY BILGE	ON AIR SYSTEM	150 PSI W.P.	29-09
24	S	¾"	GLOBE VALVE	MISCELLANEOUS	BRONZE	150 PSI W.P. @ 450°F	29-09
25	S	¾"	" "	MISCELLANEOUS	"	150 PSI W.P. @ 450°F	29-09
26	S	¾"	GATE VALVE	SERVICE GROUP STARTING AIR	"	SCREW DOWN STOP CHECK	29-09
27	S	¾"	" "	" " "	"	SCREWED BONNET	29-09
28	S	¾"	LUBRICATION	" " "	"	WELDED BONNET	29-09
29	S	¾"	" "	" " "	STEEL	"	29-09
30	S	¾"	" "	MAIN AIR	"	"	29-09
31	S	¾"	" "	CONTINUITY OF DELIVERY	"	"	29-09
32	S	¾"	GLOBE VALVE	MAIN AIR RECEIVERS		SCREWED ENDS	29-09
33	S	¾"	HOSE " "	PRESSURE TRANS	BRONZE		29-09
34	S	¾"	HOSE " "				29-09
35	S	¾"	" "		STEEL		29-09
36	S	¾"	" "				29-09
37	S	¾"	" "				29-09
38	S	¾"	" "				29-09
39	S	¾"	" "				29-09
40	S	¾"	" "				29-09
41	S	¾"	" "				29-09
42	S	¾"	" "				29-09
43	S	¾"	" "				29-09
44	S	¾"	" "				29-09
45	S	¾"	" "				29-09
46	S	¾"	" "				29-09
47	S	¾"	" "				29-09
48	S	¾"	" "				29-09
49	S	¾"	" "				29-09
50	S	¾"	" "				29-09
51	S	¾"	" "				29-09
52	S	¾"	" "				29-09
53	S	¾"	" "				29-09
54	S	¾"	" "				29-09
55	S	¾"	" "				29-09
56	S	¾"	" "				29-09
57	S	¾"	" "				29-09
58	S	¾"	" "				29-09
59	S	¾"	" "				29-09
60	S	¾"	" "				29-09
61	S	¾"	" "				29-09
62	S	¾"	" "				29-09
63	S	¾"	" "				29-09
64	S	¾"	" "				29-09
65	S	¾"	" "				29-09
66	S	¾"	" "				29-09
67	S	¾"	" "				29-09
68	S	¾"	" "				29-09
69	S	¾"	" "				29-09
70	S	¾"	" "				29-09
71	S	¾"	" "				29-09
72	S	¾"	" "				29-09
73	S	¾"	" "				29-09
74	S	¾"	" "				29-09

VALVE	SHAFT	SIZE	DESCRIPTION	FUNCTION	MATERIAL	REMARKS	FIG. OR
S.A. 75	S	¾"	125#. GATE VALVE	AIR RECEIVER, S.S.H.P.	S.S. ASTM A 276 TYPE 304	250 PSI W.P.	29-09
76	S	¾"	GLOBE "	MAIN PUR. STARTING AIR	"	"	4
77	S	¾"	"	EMERGENCY GENERATOR STARTING AIR	"	250 PSI W.P.	29-09
78	S	¾"	"	REDUCING STATION	"	"	29-09
79	S	¾"	"	DISTRIBUTION MANIFOLD	"	"	29-09
80	S	¾"	"	"	"	"	29-09
81	S	¾"	"	AUX. SERVICES, H.P.T.	"	"	29-09
82	S	¾"	"	CONTROLLER PILOTS'Y	"	"	29-09
83	S	¾"	"	DIESEL START SOLENOID CONTROL	"	"	29-13
84	S	¾"	"	ENGINE AIR MOTORS	"	"	4
85							
86	S	1¼"	300#. GLOBE VALVE	SERVICE DISPATCHED STARTING AIR	S.S. ASTM A 276 TYPE 304	250 PSI W.P.	29-09
87	S	¾"	ANGLE VALVE FOR P.O.V.	MOTOR SHAFT GENERATOR CONTROL	STEEL	"	29-09
88	S	¾"	GLOBE " "	MAIN ENGINE START VALVE	"	"	29-09
89	S	¾"	" "	CONTROL AIR			29-09
90	S	¾"	LIFT CHECK VALVE	MAIN ENGINE STARTING AIR	CAST STEEL, FLG'D 300#		29-09
91	S	¾"	" "	COMPRESSOR DELIVERY	" " "		29-09
92	S	¾"	" "	AIR TO CONTROL AIR SUPPLY			29-09
93	S	¾"	GLOBE "	WHEELHOUSE	BRONZE	150 PSI W.P. @ 450°F	29-09
94	S	¾"	" STRAINER	MAIN BILGE STARTING AIR	CAST STEEL, FLG'D 300#		29-09
95	S	¾"	" "	MAIN BILGE STARTING AIR	" " "		29-09
96	S	¾"	SCREW DOWN STOP CHECK VALVE	EMERGENCY BILGE	ON AIR SYSTEM	150 PSI W.P.	29-09
97	S	¾"	GLOBE VALVE	MISCELLANEOUS	BRONZE	150 PSI W.P. @ 450°F	29-09
98	S	¾"	" "	MISCELLANEOUS	"	150 PSI W.P. @ 450°F	29-09
99	S	¾"	GATE VALVE	SERVICE GROUP STARTING AIR	"	SCREW DOWN STOP CHECK	29-09
100	S	¾"	" "	" " "	"	SCREWED BONNET	29-09
101	S	¾"	LUBRICATION	" " "	"	WELDED BONNET	29-09
102	S	¾"	" "	" " "	STEEL	"	29-09
103	S	¾"	" "	MAIN AIR	"	"	29-09
104	S	¾"	" "	CONTINUITY OF DELIVERY	"	"	29-09
105	S	¾"	GLOBE VALVE	MAIN AIR RECEIVERS		SCREWED ENDS	29-09
106	S	¾"	HOSE " "	PRESSURE TRANS	BRONZE		29-09
107	S	¾"	HOSE " "				29-09
108	S	¾"	" "		STEEL		29-09
109	S	¾"	" "				29-09
110	S	¾"	" "				29-09
111	S	¾"	" "				29-09
112	S	¾"	" "				29-09
113	S	¾"	" "				29-09
114	S	¾"	" "				29-09
115	S	¾"	" "				29-09
116	S	¾"	" "				29-09
117	S	¾"	" "				29-09
118	S	¾"	" "				29-09
119	S	¾"	" "				29-09
120	S	¾"	" "				29-09
121	S	¾"	" "				29-09
122	S	¾"	" "				29-09
123	S	¾"	" "				29-09
124	S	¾"	" "				29-09
125	S	¾"	" "				29-09
126	S	¾"	" "				29-09
127	S	¾"	" "				29-09
128	S	¾"	" "				29-09
129	S	¾"	" "				29-09
130	S	¾"	" "				29-09
131	S	¾"	" "				29-09
132	S	¾"	" "				29-09
133	S	¾"	" "				29-09
134	S	¾"	" "				29-09
135	S	¾"	" "				29-09
136	S	¾"	" "				29-09
137	S	¾"	" "				29-09
138	S	¾"	" "				29-09
139	S	¾"	" "				29-09
140	S	¾"	" "				29-09
141	S	¾"	" "				29-09
142	S	¾"	" "				29-09
143	S	¾"	" "				29-09
144	S	¾"	" "				29-09
145	S	¾"	" "				29-09
146	S	¾"	" "				29-09

VALVE	SHAFT	SIZE	MATERIAL	PURPOSE	REMARKS	FIG. OR
B.V. 1	P	8"	FLANGED SPUD DRAINS STEEL			21-09
2	P	8"				21-09
3	P	8"				21-09
4	P	8"				21-09
5	P	8"				21-09
6	P	8"				21-09
7	P	8"				21-09
8	P	8"				21-09
9	P	8"				21-09
10	P	8"				21-09
11	P	8"				21-09
12	P	8"				21-09
13	P	8"				21-09
14	P	8"				21-09
15	P	8"				21-09
16	P	8"				21-09
17	P	8"				21-09
18	P	8"				21-09
19	P	8"				21-09
20	P	8"				21-09
21	P	8"				21-09
22	P	8"				21-09
23	P	8"				21-09
24	P	8"				21-09
25	P	8"				21-09
26	P	8"				21-09
27	P	8"				21-09
28	P	8"				21-09
29	P	8"				21-09
30	P	8"				21-09
31	P	8"				21-09
32	P	8"				21-09
33	P	8"				21-09
34	P	8"				21-09
35	P	8"				21-09
36	P	8"				21-09
37	P	8"				21-09
38	P	8"				21-09
39	P	8"				21-09
40	P	8"				21-09
41	P	8"				21-09
42	P	8"				21-09
43	P	8"				21-09
44	P	8"				21-09
45	P	8"				21-09
46	P	8"				21-09
47	P	8"				21-09
48	P	8"				21-09
49	P	8"				21-09
50	P	8"				21-09
51	P	8"				21-09
52	P	8"				21-09
53	P	8"				21-09
54	P	8"				21-09
55	P	8"				21-09
56	P	8"				21-09
57	P	8"				21-09
58	P	8"				21-09
59	P	8"				21-09
60	P	8"				21-09
61	P	8"				21-09
62	P	8"				21-09
63	P	8"				21-09
64	P	8"				21-09
65	P	8"				21-09
66	P	8"				21-09
67	P	8"				21-09
68	P	8"				21-09
69	P	8"				21-09
70	P	8"				21-09
71	P	8"				21-09
72	P	8"				21-09
73	P	8"				21-09
74	P	8"				21-09



PLAN VIEW



PART SECTION AT FR 176 LOOKING AFT



PART ELEVATION



F.P.C. TANK
AS FITTED