

## **Part 1            General**

### **1.1            ACTION AND INFORMATIONAL SUBMITTALS**

- .1    Product Data:
  - .1       Submit manufacturer's instructions, printed product literature and data sheets for grounding equipment and include product characteristics, performance criteria, physical size, finish and limitations.

### **1.2            CLOSEOUT SUBMITTALS**

- .1    Operation and Maintenance Data: submit operation and maintenance data for grounding equipment for incorporation into manual.
- .2    Provide in French (if available; if not available, the manufacturer is required to state that) and English for incorporation into manual.

### **1.3            DELIVERY, STORAGE AND HANDLING**

- .1    Deliver, store and handle materials in accordance with manufacturer's written instructions.
- .2    Delivery and Acceptance Requirements: deliver materials to site in original factory packaging, labelled with manufacturer's name and address.
- .3    Storage and Handling Requirements:
  - .1       Store materials off ground indoors in dry location and in accordance with manufacturer's recommendations in clean, dry, well-ventilated area.
  - .2       Store and protect grounding equipment from nicks, scratches, and blemishes.
  - .3       Replace defective or damaged materials with new.
- .4    Packaging Waste Management: remove for reuse and return of pallets, crates, padding, packaging materials.

## **Part 2            Products**

### **2.1            EQUIPMENT**

- .1    Grounding conductors: bare stranded copper, soft annealed, size as required by code.
- .2    Insulated grounding conductors: green, copper conductors, size as required by code.
- .3    Non-corroding accessories necessary for grounding system, type, size, material as indicated, including but not necessarily limited to:
  - .1       Grounding and bonding bushings.
  - .2       Protective type clamps.
  - .3       Bolted type conductor connectors.
  - .4       Thermit welded type conductor connectors.

- .5 Bonding jumpers, straps.
- .6 Pressure wire connectors.

### **Part 3 Execution**

#### **3.1 INSTALLATION GENERAL**

- .1 Install connectors in accordance with manufacturer's instructions.
- .2 Protect exposed grounding conductors from mechanical injury.
- .3 Use mechanical connectors for grounding connections to equipment provided with lugs.
- .4 Soldered joints not permitted.
- .5 Install bonding wire for flexible conduit, connected at both ends to grounding bushing, solderless lug, clamp or cup washer and screw. Neatly cleat bonding wire to exterior of flexible conduit.
- .6 Connect building structural steel and metal siding to ground.

#### **3.2 EQUIPMENT GROUNDING**

- .1 Install grounding connections to typical equipment included in, but not necessarily limited to following list. Service equipment, transformers, switchgear, duct systems, frames of motors, motor control centres, starters, control panels, building steel work, generators, elevators and escalators, distribution panels, outdoor lighting, cable trays.

#### **3.3 FIELD QUALITY CONTROL**

- .1 Perform tests in accordance with Section 26 05 00 - Common Work Results for Electrical.
- .2 Perform ground continuity and resistance tests using method appropriate to site conditions and to approval of Departmental Representative and local authority having jurisdiction over installation.
- .3 Perform tests before energizing electrical system.
- .4 Disconnect ground fault indicator during tests.

#### **3.4 CLEANING**

- .1 Leave Work area clean at end of each day.
- .2 Final Cleaning: upon completion remove surplus materials, rubbish, tools and equipment.
- .3 Waste Management: separate waste materials for reuse and recycling in accordance.
  - .1 Remove recycling containers and bins from site and dispose of materials at appropriate facility.

**END OF SECTION**