

Part 1 General

1.1 RELATED SECTIONS

- .1 Section 26 05 00 - Common Work Results for Electrical.
- .2 Section 33 65 73 - Concrete Encased Duct Banks and Manholes.
- .3 Section 33 65 76 - Direct Buried Underground Cable Ducts.

1.2 REFERENCES

- .1 Insulated Cable Engineers Association, Inc. (ICEA).

1.3 ACTION AND INFORMATIONAL SUBMITTALS

- .1 Submit in accordance with Section 01 33 00 - Submittal Procedures.
- .2 Product Data:
 - .1 Submit manufacturer's instructions, printed product literature and data sheets for cables and include product characteristics, performance criteria, physical size, finish and limitations.

1.4 DELIVERY, STORAGE, AND HANDLING

- .1 Deliver, store, and handle materials in accordance with manufacturer's written instructions.
- .2 Delivery and Acceptance Requirements: deliver materials to site in original factory packaging, labelled with manufacturer's name and address.
- .3 Storage and Handling Requirements:
 - .1 Store materials off ground, indoors, and in accordance with manufacturer's recommendations in clean, dry, and well-ventilated area.
 - .2 Store and protect cables from nicks, scratches, and blemishes.
 - .3 Replace defective or damaged materials with new.

Part 2 Products

2.1 NOT USED

- .1 Not used.

Part 3 Execution

3.1 EXAMINATION

- .1 Verification of Conditions: verify that conditions of substrate previously installed under other Sections or Contracts are acceptable for cable installation in accordance with manufacturer's written instructions.
 - .1 Visually inspect substrate.
 - .2 Inform Departmental Representative of unacceptable conditions immediately upon discovery.
 - .3 Proceed with installation only after unacceptable conditions have been remedied.

3.2 CABLE INSTALLATION IN DUCTS

- .1 Install cables as indicated in ducts.
- .2 Do not pull spliced cables inside ducts.
- .3 Install multiple cables in duct simultaneously.
- .4 Use CSA approved lubricants of type compatible with cable jacket to reduce pulling tension.
- .5 To facilitate matching of colour coded multiconductor control cables reel off in same direction during installation.
- .6 Before pulling cable into ducts and until cables are properly terminated, seal ends of lead covered cables with wiping solder; seal ends of non-leaded cables with moisture seal tape.
- .7 After installation of cables, seal duct ends with duct sealing compound.

3.3 FIELD QUALITY CONTROL

- .1 Perform tests in accordance with Section 26 05 00 - Common Work Results for Electrical.
- .2 Perform tests using qualified personnel.
 - .1 Include necessary instruments and equipment.
- .3 Check phase rotation and identify each phase conductor of each feeder.
- .4 Check each feeder for continuity, short circuits and grounds.
 - .1 Ensure resistance to ground of circuits is not less than 50 megohms.
- .5 Pre-acceptance tests:
 - .1 After installing cable but before splicing and terminating, perform insulation resistance test with 1,000 V megger on each phase conductor.
 - .2 Check insulation resistance after each splice and/or termination to ensure that cable system is ready for acceptance testing.

- .6 Provide Departmental Representative with list of test results showing location at which each test was made, circuit tested and result of each test.
- .7 Remove and replace entire length of cable if cable fails to meet any of test criteria.

3.4 CLEANING

- .1 Progress Cleaning: clean in accordance with Section 01 74 11 - Cleaning.
 - .1 Leave Work area clean at end of each day.
- .2 Final Cleaning: upon completion remove surplus materials, rubbish, tools and equipment in accordance with Section 01 74 11 - Cleaning.

3.5 PROTECTION

- .1 Repair damage to adjacent materials caused by cables installation.

END OF SECTION