

Part 1 General**1.1 ACTION AND INFORMATIONAL SUBMITTALS**

- .1 Submit in accordance with Section 01 00 10 – General Instructions.
- .2 Product Data:
 - .1 Submit manufacturer's instructions, printed product literature and data sheets for diffusers, registers and grilles and include product characteristics, performance criteria, physical size, finish and limitations.
 - .2 Indicate following:
 - .1 Capacity.
 - .2 Throw and terminal velocity.
 - .3 Noise criteria.
 - .4 Pressure drop.
 - .5 Neck velocity.
 - .6 Finish.

1.2 DELIVERY, STORAGE AND HANDLING

- .1 Deliver, store and handle materials in accordance with Section 01 00 10 – General Instructions.
- .2 Delivery and Acceptance Requirements: deliver materials to site in original factory packaging, labelled with manufacturer's name and address.
- .3 Storage and Handling Requirements:
 - .1 Store materials indoors and in accordance with manufacturer's recommendations in clean, dry, well-ventilated area.
 - .2 Store and protect diffuser, registers and grilles from nicks, scratches, and blemishes.
 - .3 Replace defective or damaged materials with new.
- .4 Packaging Waste Management: remove for reuse and recycling of pallets, crates, padding, packaging materials as specified in Section 01 00 10 – General Instructions.

Part 2 Products**2.1 SYSTEM DESCRIPTION**

- .1 Performance Requirements:
 - .1 Catalogued or published ratings for manufactured items: obtained from tests carried out by manufacturer or those ordered by manufacturer from independent testing agency signifying adherence to codes and standards.

2.2 GENERAL

- .1 To meet capacity, pressure drop, terminal velocity, throw, noise level, neck velocity as indicated.

- .2 Frames:
 - .1 Full perimeter gaskets.
 - .2 Plaster frames where set into plaster or gypsum board and as specified.
 - .3 Concealed fasteners.
- .3 Concealed manual volume control damper operators.
- .4 Colour: as directed by Departmental Representative.

2.3 MANUFACTURED UNITS

- .1 Grilles, registers and diffusers of same generic type, products of one manufacturer.

2.4 SUPPLY GRILLES AND REGISTERS

- .1 As scheduled on drawings.

Part 3 Execution

3.1 EXAMINATION

- .1 Verification of Conditions: verify that conditions of substrate previously installed under other Sections or Contracts are acceptable for diffuser, register and grille installation in accordance with manufacturer's written instructions.
 - .1 Visually inspect substrate in presence of Departmental Representative .
 - .2 Inform Departmental Representative of unacceptable conditions immediately upon discovery.
 - .3 Proceed with installation only after unacceptable conditions have been remedied and after receipt of written approval to proceed from Departmental Representative .

3.2 INSTALLATION

- .1 Install in accordance with manufacturer's instructions.
- .2 Install with oval head stainless steel screws.

3.3 CLEANING

- .1 Progress Cleaning: clean in accordance with Section 01 00 10 – General Instructions.
 - .1 Leave Work area clean at end of each day.
- .2 Final Cleaning: upon completion remove surplus materials, rubbish, tools and equipment in accordance with Section 01 00 10 – General Instructions.
- .3 Waste Management: separate waste materials for reuse and recycling in accordance with Section 01 00 10 – General Instructions.
 - .1 Remove recycling containers and bins from site and dispose of materials at appropriate facility.

END OF SECTION