


Canada

100-1960 Robertson Road, Suite 100
Ottawa (Ontario) K2H 5B9
(613) 596-6454
(613) 596-3346_Fax
www.bpa.ca


bpa

1960, chemin Robertson, bureau 100
Ottawa (Ontario) K2H 5B9
(613) 596-6454
(613) 596-3346 – télécopieur
www.bpa.ca


mechanical | electrical | energy | telecommunications
mécanique | électricité | efficacité énergétique | télécommunications



KEY PLAN
PLAN-REPÈRE

N.T.S.
PAS À L'ÉCHELLE

PROJECT NORTH
NORD DU PROJET



4	ISSUED FOR TENDER	2015-04-15
3	ISSUED FOR 100% REVIEW - TENDER	2015-01-30
2	ISSUED FOR 99% REVIEW	2014-10-23
1	ISSUED FOR 66% REVIEW	2014-09-09

revisions	description	date
<div><div>A</div><div>C</div></div>	A detail no. no du détail B location drawing no. no du dessin de localisation C drawing no. no du dessin	<div><div>A</div><div>B</div><div>C</div></div>

project

projet

CHILLER REPLACEMENT
FOR TRANSPORT CANADA
TRAINING CENTRE
(BUILDING O-276)

drawing

dessin

HYDRAULIC BUILDING
PLUMBING
REMOVALS AND NEW WORK


Designed By	CARL MUIR	Conçu par
Date	2014-08-21	(yyyy/mm/dd)
Drawn By	CARL MUIR	Dessiné par
Date	2014-08-21	(yyyy/mm/dd)
Reviewed By	DAVID LANDSBERG	Examiné par
Date	2014-09-10	(yyyy/mm/dd)
Approved By	DAVID LANDSBERG	Approuvé par
Date	2014-09-10	(yyyy/mm/dd)
Tender	2015-01-30	Soumission
Project Manager	K. DUNN	Administrateur de projet
Project no.		no du projet

R.060139.002

Drawing no.

no du dessin

M201



GENERAL NOTES:

- LOUD MACHINERY IN OPERATION AT ALL TIMES WITHIN HYDRAULIC BUILDING. USE CAUTION AND PROTECT EQUIPMENT AT ALL TIMES.

DRAWING NOTES:

- EXISTING AIR COMPRESSOR TO BE DISCONNECTED AND RELOCATED. COORDINATE FINAL POSITION OF THE AIR COMPRESSOR WITH EXISTING ELECTRICAL PANEL AND NEW MODULAR CHILLERS IN ORDER TO MAINTAIN MINIMUM REQUIRED CLEARANCES.
- DISMANTLE DOMESTIC PIPING BACK TO THIS POINT.
- EXISTING STORM PIPING TO REMAIN.
- EXISTING ROOF DRAIN TO BE DISMANTLED AND REPLACED WITH NEW.
- RETAIN BACKFLOW PREVENTER FOR REINSTALLATION.
- EXISTING AIR DRYER TO BE DISCONNECTED AND RELOCATED. INSTALL THE EXISTING AIR DRYER ABOVE THE AIR COMPRESSOR, ON ANGLED IRON BRACKETS.
- ADJUST SUPPLY PRESSURE AS PER CLIENTS INSTRUCTIONS.
- SUPPLY AND INSTALL A NEW FUNNEL TO THE EXISTING FLOOR DRAIN.

