



- ① **TYPICAL:**
DISCONNECT AND REMOVE EXISTING ELECTRICAL DEVICES AS SHOWN. REMOVE CONDUIT AND WIRING BACK TO SOURCE AND MAKE SAFE.
- ② DISCONNECT AND REMOVE EXISTING ELECTRICAL PANEL AS INDICATED. REMOVE CONDUIT AND WIRING BACK TO SOURCE AND MAKE SAFE. TRANSFER ALL EXISTING TO REMAIN ELECTRICAL CIRCUITS TO NEW PANEL RP1 LOCATED IN NEW MECHANICAL ROOM. REFER TO DRAWING ES FOR EXACT LOCATION.
- ③ EXISTING WALL MOUNTED AC UNITS TO BE RELOCATED BY MECHANICAL TRADES. DISCONNECT AND REMOVE AND RECONNECT UPON COMPLETION OF WORK. EXTEND CONDUIT AND WIRING AS REQUIRED. PROVIDE NEW WALL MOUNTED DISCONNECT SWITCH AT EACH UNIT. REFERENCE DRAWING ES FOR NEW LOCATION.

Drawing no. _____ No. du dessin _____

E4