

PART 1 - GENERAL

- 1.1 REFERENCES
- .1 Canada Green Building Council (CaGBC)
    - .1 LEED Canada 2009 for Design and Construction-2010, LEED Canada 2009 for Design and Construction Leadership in Energy and Environmental Design Green Building Rating System Reference Guide.
  - .2 Canadian General Standards Board (CGSB)
    - .1 CAN/CGSB-44.40-01, Steel Clothing Locker.
- 1.2 ACTION AND INFORMATIONAL SUBMITTALS
- .1 Submit submittals in accordance with Section 01 33 00 - Submittal Procedures.
  - .2 Product Data:
    - .1 Provide manufacturer's printed product literature and data sheets for metal lockers and include product characteristics, performance criteria, physical size, finish and limitations.
  - .3 Shop Drawings:
    - .1 Indicate on drawings: type and class of locker, thicknesses of metal, fabricating and assembly methods, assembled banks of lockers, tops, rods, hooks, shelves, bases, trim, numbering, filler panels, end/back panels, doors, handles, locking method, ventilation method and finishes.
  - .4 Samples:
    - .1 Submit duplicate 50 x 50 mm samples of colour and finish on actual base metal.
    - .2 Samples will be returned for inclusion into work.
  - .5 Sustainable Design Submittals:
    - .1 LEED Canada-NC Version 1.0 Submittals: in accordance with Section 01 35 21 - LEED Requirements.
-

1.3 DELIVERY,  
STORAGE AND  
HANDLING

- .1 Deliver, store and handle materials in accordance with Section 01 61 00 - Common Product Requirements and with manufacturer's written instructions.
- .2 Delivery and Acceptance Requirements:
  - .1 Deliver materials to site in original factory packaging, labelled with manufacturer's name and address.
- .3 Storage and Handling Requirements:
  - .1 Store materials indoors in dry location and in accordance with manufacturer's recommendations in clean, dry, well-ventilated area.
  - .2 Store and protect metal lockers from nicks, scratches, and blemishes.
  - .3 Replace defective or damaged materials with new.
- .4 Packaging Waste Management: remove for reuse and return by manufacturer of pallets, crates, padding, and packaging materials in accordance with Section 01 74 21 - Construction/Demolition Waste Management and Disposal.
  - .1 Materials and Resources Credit MRC2.2 Construction Waste Management: Construction Waste Management: Divert 75% From Landfill: prepare Construction Waste Management plan in accordance with Section 01 74 21 - Construction/Demolition Waste Management and Disposal and Section 01 35 21 - LEED Requirements 01 78 00 - Closeout Submittals.

PART 2 - PRODUCTS

2.1 MANUFACTURED  
UNITS

- .1 Lockers: to CAN/CGSB-44.40, Type 1-Single full-height locker Class 2 - A bank of two or more lockers.
  - .1 Size: 305 mm wide x 460 mm deep x 1830 mm high, steel thickness No. 20 MSG.
  - .2 Assembly: knock down construction.
  - .3 Top: sloped.
  - .4 Doors: one-piece double-wall envelope construction, steel thickness No. 20 MSG, door

2.1 MANUFACTURED .1 Lockers: (Cont'd)  
UNITS .4 Doors: (Cont'd)  
(Cont'd) swing to be confirmed by Departmental  
Representative.  
.5 Door handle: recessed handle steel with  
bright chromium.

2.2 ACCESSORIES .1 Locking system: padlocks supplied by others.  
Recessed handle and lock pocket.  
.2 Options: to CAN/CGSB-44.40, hanger rods,  
steel with chromium steel base, steel end  
panels, steel trim including corner angles,  
jamb trim, fillers, number plates  
manufacturer's standards, coat hooks, metal  
chromium finish.

PART 3 - EXECUTION

3.1 EXAMINATION .1 Verification of Conditions: verify conditions  
of substrates and surfaces to receive metal  
lockers previously installed under other  
Sections or Contracts are acceptable for  
product installation in accordance with  
manufacturer's instructions prior to metal  
locker installation.  
.2 Inform Departmental Representative of  
unacceptable conditions immediately upon  
discovery.  
.3 Proceed with installation only after  
unacceptable conditions have been remedied and  
after receipt of written approval from  
Departmental Representative.

3.2 INSTALLATION .1 Assemble and install lockers in accordance  
with manufacturer's written instructions.  
.2 Securely fasten lockers to grounds and  
nailing strips.

- END