



DETAIL A



"T" BULHEAD
SUPPORT DETAILS



A

NOTE: BULKHEAD SUPPORTS
CONFORM WITH ISOLAMIN PANEL
INSTALLATION INSTRUCTIONS
REGARDING THE SPACING OF 600 MM
FOR CHANNEL FASTENERS

"T" BULKHEAD SUPPORT BRACKETS
ARE REQUIRED TO BE FITTED PRIOR
TO INSTALLING A DEX-D-TEX A-60
FLOOR IN ORDER TO:

- A) SUPPORT THE BULKHEADS
DURING THE FLOOR INSTALLATION
- B) LOCATE AND SECURE THE
BULKHEADS AFTER THE FLOORING
INSTALLATION

rev	description	by	date
drawing - dessin			
ISOLAMIN PANEL BULHEAD SUPPORT DETAILS			
drawn - dessiné		date	
B.H.		MARCH 12, 2012	
checked - vérifié		date	
approved - approuvé		date	