

PART 1 - GENERAL

- | | | |
|------------------------------------|----|---|
| <u>1.1 DESCRIPTION</u> | .1 | This section specifies requirements for supply and installation of treated timber and necessary fastenings for fabrication, placing, and ballasting of timber cribwork. |
| <u>1.2 RELATED SECTIONS</u> | .1 | Section 01 74 21 - Construction/Demolition Waste Management and Disposal. |
| | .2 | Section 06 05 73 - Wood Treatment. |
| <u>1.3 MEASUREMENT FOR PAYMENT</u> | .1 | <u>Treated Timber Cribwork</u> : to be measured in cubic metres (m ³) of completed work which includes ballast stone, treated timber, fastenings, geotextile, and all plant, labour, materials and equipment to perform work. Include the connection plate and lunette eye on the outside face of the crib and the galvanized eye bolts at 600mm above L.N.T. (as shown on the drawings) as incidental to the price for treated timber cribwork. |
| | .2 | Measure timber cribwork in cubic metres determined by product. Use following dimensions measured in place:
.1 Height: average of measurements taken at each vertical from bottom of lowest timber to top side of uppermost course of timber.
.2 Width: average of measurements between outside faces of exterior longitudinal timbers, each width measured on top ties of each row of cross ties.
.3 Length: measured horizontally along centre-line of crib between outside faces of exterior cross ties. |

- .3 Measurements of the vertical lengths, widths and lengths of cribwork, will be taken in the presence of both the Contractor and the Inspector and will be verified and signed by both parties on the site to avoid any disputes. Departmental Representative will make final approval in this regard, as there will be no overpayment for cribwork not actually installed in the work.

1.4 SAFETY REQUIREMENTS

- .1 Worker protection:
 - .1 Workers must wear gloves, respirators, dust masks, long sleeved clothing, eye protection, protective clothing when handling, drilling, sawing, cutting or sanding preservative treated wood and applying preservative materials.
 - .2 Workers must not eat, drink or smoke while applying preservative material.
 - .3 Clean up spills of preservative materials immediately with absorbent material. Safely discard of absorbent material to sanitary landfill.

1.5 REFERENCES

- .1 American Society for Testing and Materials (ASTM International)
 - .1 ASTM A307-07b, Specification for Carbon Steel Bolts and Studs, 60,000 PSI Tensile.
 - .2 ASTM C136-06, Standard Test Method for Sieve Analysis of Fine and Coarse Aggregates.
- .2 American Wood-Preserver's Association (AWPA)
 - .1 AWPA M4-06, Standard for the Care of Preservation - Treated Wood Products.

- .3 Canadian Standards Association (CSA International)
 - .1 CSA B111-1974(R2003), Wire Nails, Spikes and Staples.
 - .2 CAN/CSA-G40.21-04, General Requirements for Rolled or Welded Structural Quality Steel/Structural Steel.
 - .3 CAN/CSA G164-M92(R2003), Hot Dip Galvanizing of Irregularly Shaped Articles.
 - .4 CAN/CSA-O80 Series-97 (R2007), Wood Preservation.
- .4 Canadian Wood Council
 - .1 Wood Design Manual.
- .5 National Lumber Grades Authority (NLGA)
 - .1 Standard Grading Rules for Canadian Lumber 2000 edition.

1.6 SUBMITTALS

- .1 Ballast:
 - .1 Submit proposed placing method to Departmental Representative for approval, prior to placing of ballast.

1.7 WASTE MANAGEMENT

- .1 Remove from site and dispose of packaging materials at appropriate recycling facilities.
- .2 Dispose of all corrugated cardboard and polystyrene plastic packaging material in appropriate on-site bin for recycling.
- .3 Place materials defined as hazardous or toxic in designated containers.
- .4 Ensure emptied containers are sealed and stored safely.
- .5 Do not dispose of preservative treated

wood through incineration.

- .6 Do not dispose of preservative treated wood with other materials destined for recycling or reuse.
- .7 Dispose of treated wood, end pieces, wood scraps and sawdust at a sanitary landfill.
- .8 Dispose of unused preservative material at an official hazardous material collections site. Do not dispose of unused preservative material into sewer system, streams, lakes, on ground or in any other location where they will pose a health or environmental hazard.

PART 2 - PRODUCTS

2.1 MATERIALS

- .1 Timber: Use timber graded and stamped in accordance with applicable grading rules and standards of associations or agencies approved to grade lumber by Canadian Lumber Standards Accreditation Board of CSA.
- .2 Species: Douglas Fir, Pacific Coast Hemlock and Eastern Hemlock.
- .3 Grade: No. 1 Structural.
- .4 Grading authority: NLGA.
- .5 Preservative treatment: To CSA O80 for coastal waters and Section 06 05 73. Supply timbers in lengths required. Cut and field treat timbers only as may be necessary to suit site conditions. Contractor will have on site sufficient lengths and thickness of treated timber to

permit leveling of cribs after ballasting operations.

- .6 Miscellaneous steel: Medium structural steel conforming to CSA Specification G40.21 "Structural Quality Steels".
 - .1 Hot dip galvanized: to CAN/CSA-G164. Minimum weight of zinc coating as stated in Table 1 of this Standard. Fabricator to adhere to recommendations in Appendix A and B of Standard.
 - .2 Wire nails, spikes, staples: to CSA-B111.
 - .3 Bolts, nuts, washers: to ASTM A307.
 - .4 Drift Bolts: to G40.21 from round stock, button head and diamond or wedge point.
 - .5 Washers:
 - .1 Round Plate Washers: for 19 mm diameter machine bolts, 79 mm diameter by 7.9 mm thick, with hole diameter of 21 mm. Washers to G40.21.
 - .2 Square washers not permitted to be used.
 - .6 All hardware galvanized.
- .7 Ballast for filling cribs to following requirements:
 - .1 Stone, consisting of hard durable particles free from clay lumps, organic material and other deleterious materials.
 - .2 Dry density in place: minimum 2600 kg per cubic metre.
 - .3 Ballast stone to be well graded with maximum sizes not exceeding 400 mm on any side and minimum size of not less than 250 mm on any side.

PART 3 - EXECUTION

3.1 PREPARATION

- .1 Excavate area of crib base to elevation indicated on drawings or to bedrock (whichever occurs first). Place rock mattress to elevation shown on drawings.
- .2 Contractor to confirm with Departmental Representative that excavated cribseat is adequate for cribwork placement.
- .3 Before construction, stockpile sufficient ballast to completely fill cribs. Provide suitable plant and equipment to keep crib in proper position and alignment during sinking operations.
- .4 Take closely spaced accurate soundings and probings, 1500 mm centre to centre or less, precisely located by template, to determine actual configuration of base area of crib.
- .5 Crib out of alignment or not correctly located to be refloated and replaced in correct position.

3.2 CRIB CONSTRUCTION

- .1 Construct timber cribwork to 400 mm above LNT prior to sinking in final position in work.
- .2 Levelling Pieces:
 - .1 Place treated timber levelling pieces beneath bottom timbers to conform to shape of base area.
 - .2 Place levelling pieces horizontally.
 - .3 Secure succeeding pieces at intersections of bottom timbers and vertical posts, and other levelling pieces with machine bolts.

- .3 Bottom timbers:
 - .1 Place bottom timbers lengthwise, and crosswise to form bottom three courses of cribs.
 - .2 Crosswise bottom timbers to be of one piece.
 - .3 Lengthwise bottom timbers to be of one piece.
 - .4 Secure three courses of bottom timbers together with machine bolts at every intersection with each other and with vertical posts.
- .4 Ballast floor:
 - .1 Place ballast floor on pockets on bottom or middle course of bottom timbers.
 - .2 Secure each ballast floor timber to bottom timbers with drift bolts securing adjacent ballast floor timbers to same bottom timber.
- .5 Longitudinals:
 - .1 Longitudinals one length.
 - .2 Secure longitudinals to intersection of cross ties with drift bolt and to intersection of vertical posts with machine bolt every third course of longitudinals, along with the top course.
 - .3 Countersink machine bolts on exterior face above LNT.
- .6 Cross ties: one length across cribs.
 - .1 Secure cross ties to intersection of longitudinals with drift bolt and to intersection of vertical posts with machine bolt every third course of cross tie, along with the top course.
- .7 Vertical posts: one length from bottom of cribwork to top of cribwork.

.8 Levelling: treated timber required for levelling of cribwork after ballasting, must be full width continuous over entire length to be levelled.

.9 Bolt Sizing and Holing:

.1 Drift Bolts: length of drift bolts equal to thickness of timbers fastened less 50 mm, unless otherwise specified. Bore holes for drift bolts 2 mm smaller diameter than bolt and for full length of bolt.

.2 Machine Bolts: length of machine bolts equal to thickness of timbers fastened plus thickness of washers plus 40 mm. Where bolts are countersunk, the length, as noted above, less depth of countersink. Thread machine bolts for 64 mm. Bore holes for machine bolts to same diameter as bolts.

3.3 HANDLING TREATED TIMBER

.1 Handle treated material without damaging original treatment.

.1 Replace treated timber with major damage to original treatment, as instructed by Departmental Representative.

.2 Field treatment: to CAN/CSA-O80. Apply and saturate cuts, minor surface damage, abrasions, and nail and spike holes with preservative.

.3 Ripping of treated timber not permitted without prior approval of Departmental Representative.

3.4 BALLAST

.1 Place ballast to avoid damage to timber cribwork.

.2 Ballast to underside of beams.

3.5 TOLERANCES .1 Locate cribs within 100 mm of location as indicated.

3.6 PROTECTION .1 Protect work from damage resulting from work on other sections and from damage resulting from environmental conditions.

.2 Repair or replace portion or entire crib at no additional cost if damaged by work.