





.4 Install sleeves where conduits pass through timber.

.5 Install junction boxes for lighting on sides of poles in locations shown. Secure in place and fill with packing to be removed after concrete is placed.

.6 Ensure system is intact and clear after concrete is poured. Remove and replace any blocked conduit.

.7 Install pull rope in empty conduit before pouring concrete.

.8 Swab conduits when system is complete.

.9 Dry conduits out before installing wire.

.10 Install rigid PVC conduit above grade except where noted otherwise on drawings.