



- GENERAL NOTES:
1. ALL DIMENSIONS IN MILLIMETRES.
  2. ALL SOUNDINGS & ELEVATIONS IN METRES.



- NOTES:
1. REINSTALL FILTER STONE AND ARMOUR STONE SALVAGED FROM THE EXISTING BREAKWATER STEM SECTION IN THE NEW RE-ALIGNED STEM SECTION. THE LARGER ARMOUR STONE WILL BE PLACED ON THE SEAWARD SLOPE OF THE NEW STRUCTURES. START MATERIAL PLACEMENT FROM THE SOUTHWEST AND PROCEED NORTHEASTWARD UNTIL ALL SALVAGED MATERIAL IS USED
  2. EXACT LAYER THICKNESS OF SALVAGED ROCK MAY VARY FROM THAT SHOWN.
  3. RELOCATE AND ADJUST EXISTING ARMOUR STONE AND FILTER STONE ON EXISTING STRUCTURE AS REQUIRED TO ENSURE THE NEW MATERIAL IS INCORPORATED INTO THE WORK SUCH THAT THE ENTIRE STRUCTURE IS BONDED TOGETHER AND CONSOLIDATED AS MUCH AS POSSIBLE
  4. INSTALL 150mm THICK MAINTENANCE MATERIAL OVER NEW SERVICE AREA TO FINISH GRADE.

