


- KEYNOTES**
- 1 ABANDON EXISTING SANITARY MANHOLE. REMOVE TOP 1m AND FILL WITH FLOWABLE FILL. RETURN FRAME AND COVER TO AAFCS FACILITIES MANAGEMENT.
 - 2 CONNECT EXISTING SANITARY PIPING TO NEW PIPING. ENSURE WATERTIGHT CONNECTION. USE SOLID SLEEVE CONNECTION, OR BELL AND SPIGOT CONNECTION.
 - 3 MAINTAIN SWALE AND POSITIVE DRAINAGE.
 - 4 FILL ABANDONED PIPE ENDS WITH CEMENTITIOUS BRICK AND MORTAR.
 - 5 CONTRACTOR TO RESTRAIN POWER POLES IN ACCORDANCE WITH WORKSAFE N.B. REGULATIONS AND UTILITY COMPANIES RECOMMENDATIONS.
 - 6 REMOVE AND REPLACE EXISTING MANHOLE.



PROFILE

SCALE: 1:500 HORIZ.
1:50 VERT.



revisions: [] date: []
project: PRC SANITARY SEWER UPGRADES FREDERICTON POTATO RESEARCH CENTRE YORK CO., NB
drawing: [] dessin: []

PLAN AND PROFILE
STA. 1+000 TO STA. 1+260

designed: TWA conçu: []
date: []
drawn: KW/TWA dessiné: []
date: []
approved: [] approuvé: []
date: []
Tender: []
PWGSC Project Manager: [] Administrateur de projets TPSGC
project number: [] no. du projet: []
drawing no.: [] no. du dessin: []
R.058866.001
C3