



NOTES

1. ALL CONDUITS TO BE TIED TO TOP OF BOTTOM MAT OF REBAR ON PLASTIC CHAIRS WITH PLASTIC ZIP TIES.