

PART 1 - GENERAL

<u>1.1 Related Sections</u>	.1	Section 01 33 00 - Submittal Procedures.
	.2	Section 01 74 21 - Construction/Demolition Waste Management And Disposal.
	.3	Section 06 10 10 - Rough Carpentry
<u>1.2 References</u>	.1	Canadian Standards Association (CSA) .1 CSA 080 Series-08 (R2012), Wood Preservation. .2 CSA 0322-02 (R2012), Procedure for Certification of Pressure-Treated Wood Materials for Use in Preserved Wood Foundations.
<u>1.3 Certificates</u>	.1	Submit certificates in accordance with Section 01 33 00 - Submittal Procedures.
	.2	For products treated with preservative by pressure impregnation submit following information certified by authorized signing officer of treatment plant: .1 Information listed in AWPA M2 and revisions specified in CSA 080 Series, Supplementary Requirement to AWPA M2 applicable to specified treatment. .2 Moisture content after drying following treatment with water-borne preservative.
<u>1.4 Waste Management and Disposal</u>	.1	Do not dispose of preservative treated wood through incineration or with other materials destined for recycling or reuse.

PART 2 - PRODUCTS

- | | | |
|----------------------|----|---|
| <u>2.1 Materials</u> | .1 | Preservative Treatment: Treat to CSA 080, for coastal waters. |
| | .2 | Ladder uprights to have their ends cut as per drawings prior to treatment. Unnecessary field cutting will not be permitted. |

PART 3 - EXECUTION

- | | | |
|---|----|---|
| <u>3.1 Application:
Preservative</u> | .1 | Treat to CSA 080 Series using CCA preservative to obtain minimum net retention specified. |
| <u>3.2 Application:
Field Treatment</u> | .1 | Comply with AWPA M4 and revisions specified in CSA 080 Series, Supplementary Requirements to AWPA M2. |

PART 1 - GENERAL

- | | | |
|------------------------------------|----|---|
| <u>1.1 Related Sections</u> | .1 | Section 01 74 21 - Construction/Demolition Waste Management And Disposal. |
| | .2 | Section 06 05 73 - Wood Treatment. |
| <u>1.2 References</u> | .1 | Canadian Standards Association (CSA)
.1 CAN/CSA-G164, Hot Dip Galvanizing of Irregularly Shaped Articles.
.2 CAN/CSA-O141-05 (R2009), Softwood Lumber. |
| | .2 | National Lumber Grades Authority (NLGA)
.1 Standard Grading Rules for Canadian Lumber 2010. |
| <u>1.3 Quality Assurance</u> | .1 | Lumber by grade stamp of an agency certified by Canadian Lumber Standards Accreditation Board. |
| <u>1.4 MEASUREMENT FOR PAYMENT</u> | .1 | Treated timber wheelguard and wheelguard chocks supplied and installed will be measured in cubic metres (m3) of timber secured in place including all galvanized or stainless steel fastenings as shown, plant, material, and labour. |

PART 2 - PRODUCTS

- | | | |
|----------------------|----|--|
| <u>2.1 Materials</u> | .1 | Use timber graded and stamped in accordance with applicable grading rules and standards of Associations or Agencies approved to grade lumber by Canadian Lumber Standards Administration Board of CSA. |
| | .2 | Species |
-

- .1 Structural timber species: Hemlock or Douglas Fir (CCA Treated).
- .2 Grade: No.1 Structural Grade with maximum of 20% of a lesser grade.

2.2 Wood
Preservative

- .1 In accordance with Section 06 05 73.

PART 3 - EXECUTION

3.1 Installation

- .1 Comply with requirements of NBC 2010.
- .2 Install members true to line, levels and elevations, square and plumb.
- .3 Construct continuous members from pieces of longest practical length.
- .4 Install spanning members with "crown-edge" up.

3.2 FIELD CUTTING
TREATED TIMBER

- .1 Field cuts are to be minimal to suit field conditions. Follow best practices by cutting and field preserving treated timber in one location over a ground sheet and collect all saw dust, scraps and drippings for disposal at an approved disposal site.
 - .2 Treat, in field, cuts and damage to surface of treated material with an appropriate preservative as described in CSA O80 Series. Ensure that damaged areas such as abrasions, nail and spike holes are thoroughly saturated with field treatment solutions as per CSA O80 Series.
 - .3 Treat bolt holes, cutoffs and field cuts in accordance with CSA O80 Series.
-

PWGSC	Rough Carpentry	Section 06 10 10
Training Wall		Page 3
Reconstruction 401		
Miller Brook, NB		2015-12-29
R.075620.001		

3.3 TIMBER	.1	Install new Timber wheelguard and chocks as
<u>WHEELGUARD</u>		shown on plan or as directed by the
		Departmental Representative.