



1 ALL DIMENSIONS ARE GIVEN IN FEET AND INCHES UNLESS MARKED OTHERWISE.

2 TEST HEADS SHOWN IN TABLES ARE FOR WATER TESTING ONLY.

3 ALL DOUBLE BOTTOM, BILGE, PEAK OIL AND WATER STRUCTURAL TANKS SHALL BE
WATER TESTED UNDER HEAD TO C.G.S.I AND LLOYDS REQUIREMENTS PRIOR TO
LAUNCHING THE VESSEL AND AFTER ALL VALVES, FITTINGS, ETC, HAVE BEEN
FITTED IN PLACE.

4 NO TANK SHALL BE COATED OR PAINTED OR OTHERWISE COVERED UNTIL WATER
TESTING HAS BEEN COMPLETED AND PASSED BY ALL PARTIES CONCERNED.

HYDROSTATIC TEST	DRY SURVEY INSPECTION			SPACE NO.	TANK	CONTENTS	TEST HEAD	REMARKS
	LLOYDS	COS-1	D.S.S.					
				101	SEA BOX	WATER BALLAST		
				102	LUB OIL TANK-PORT	LUB OIL		
				105	LUB OIL TANK-STBD	LUB OIL		
				106	NO 4 D/B OIL FUEL TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				107	NO 4 D/B OIL FUEL TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				110	LOW SEA BOX-PORT	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 112
				111	LOW SEA BOX-STBD	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 112
				112	SEA BAY	WATER BALLAST	5'-2" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				113	NO 3 D/B OIL FUEL TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				114	NO 3 D/B OIL FUEL TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				115	LOW SEA BOX-PORT	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 119
				116	LOW SEA BOX-STBD	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 119
				117	LOW SEA BOX-PORT	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 120
				118	LOW SEA BOX-STBD	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 120
				119	SEA BAY	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				120	SEA BAY	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				121	NO 2 D/B OIL FUEL TANK-PORT	DIESEL OIL	5'-1" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				122	NO 2 D/B OIL FUEL TANK-STBD	DIESEL OIL	5'-1" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				123	DIRTY OIL TANK	LUB OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, BELOW MAIN DECK
				124	BULGE RETENTION TANK	ONLY WATER	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				125	SEA BOX	WATER BALLAST		
				126	DUCT KEEL		5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				127	NO 1 D/B OIL FUEL TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				128	NO 1 D/B OIL FUEL TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				129	SEA BOX	WATER BALLAST		
				201	AFT TRIMMING TANK	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				202	OIL FUEL TANK-PORT	DIESEL OIL	5'-2" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				223	OIL FUEL TANK-STBD	DIESEL OIL	5'-2" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				205	SEA BOX	WATER BALLAST		
				206	HIGH SEA BOX	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 112
				208	OIL FUEL TANK-PORT	DIESEL OIL	5'-4" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				209	OIL FUEL TANK-STBD	DIESEL OIL	5'-4" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				210	HIGH SEA BOX-PORT	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 119
				211	HIGH SEA BOX-STBD	WATER BALLAST		BLANK OFF WHILE TESTING SPACE NO 120
				213	OIL FUEL TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				214	OIL FUEL TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				215	OIL FUEL SETTLING TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				216	OIL FUEL SETTLING TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				217	LOWER FLUME TANK	DIESEL OIL	5'-1" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				219	OIL FUEL TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				220	OIL FUEL TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				221	OIL FUEL TANK-PORT	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				222	OIL FUEL TANK-STBD	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				301	AFT PEAK TANK	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				303	COFFERDAM		5'-3" ABOVE CROWN OF TANK	
				304	HELICOPTER FUEL TANK	AVIATION	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE
				305	POTABLE WATER TANK-PORT	POTABLE WATER	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				306	POTABLE WATER TANK-STBD	POTABLE WATER	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				311	FEED WATER TANK-PORT	POTABLE WATER	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				312	FEED WATER TANK-STBD	POTABLE WATER	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				316	OIL FUEL DAY TANK	DIESEL OIL	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				318	UPPER FLUME TANK	DIESEL OIL	5'-5" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				319	HEELING TANK-PORT	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				320	HEELING TANK-STBD	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				326	FORWARD TRIMMING TANK	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				329	FORE PEAK TANK	WATER BALLAST	5'-3" ABOVE CROWN OF TANK	TO TOP OF AIR PIPE, 30" ABOVE UPPER DECK
				659	BOILER FUEL OIL TANK	DIESEL OIL	8'-0" ABOVE CROWN OF TANK	
				806	EMERGENCY GEN FUEL OIL TANK	DIESEL OIL	8'-0" ABOVE CROWN OF TANK	

[illegible]