

P/N: 711872/721941  
Wharf Reconstruction  
Musgrave Harbour, NL

PART 1 - GENERAL

1.1 RELATED  
SECTIONS

- .1 Section 03 20 00 - Concrete Reinforcing.
- .2 Section 03 30 00 - Cast-in-Place Concrete.
- .3 Section 07 92 10 - Joint Sealing.

1.2 REFERENCES

- .1 Canadian Standards Association (CSA)
  - .1 CAN/CSA-A23.1-09, Concrete Materials and Methods of Concrete Construction.
  - .2 CAN/CSA-086-09, Engineering Design in Wood.
  - .3 CSA 0121-08, Douglas Fir Plywood.
  - .4 CSA 0151-09, Canadian Softwood Plywood.
  - .5 CSA 0153-M1980 (R2008), Poplar Plywood.
  - .6 CAN3-0188.0-M78, Standard Test Methods for Mat-Formed Wood Particleboards and Waferboard.
  - .7 CSA 0437 Series-93 (R2006), Standards for OSB and Waferboard.
  - .8 CSA S269.1-1975 (R2003), Falsework for Construction Purposes.
  - .9 CAN/CSA-S269.3-M92 (R2008), Concrete Formwork.

1.3 SHOP DRAWINGS

- .1 Submit shop drawings for formwork and falsework in accordance with Section 01 33 00 - Submittal Procedures.
- .2 Indicate method and schedule of construction, shoring, stripping and re-shoring procedures, materials, arrangement of joints, special architectural exposed finishes, ties, liners, and locations of temporary embedded parts. Comply with CSA S269.1, for falsework drawings Comply with CAN/CSA-S269.3 for formwork drawings.
- .3 Indicate formwork design data, such as

P/N: 711872/721941  
Wharf Reconstruction  
Musgrave Harbour, NL

Page 2  
2018-02-02

---

permissible rate of concrete placement, and  
temperature of concrete, in forms.

- .4 Indicate sequence of erection and removal of  
formwork/falsework as directed by  
Departmental Representative.
- .5 Each shop drawing submission shall bear stamp  
and signature of qualified Professional  
Engineer registered or licensed in Province  
of Newfoundland and Labrador, Canada.

#### 1.4 WASTE MANAGEMENT AND DISPOSAL

- .1 Separate and recycle waste materials in  
accordance with Section 01 74 21 -  
Construction/Demolition Waste Management and  
Disposal and the Waste Reduction Workplan.
- .2 Place materials defined as hazardous or toxic  
waste in designated containers.
- .3 Ensure emptied containers are sealed and  
stored safely for disposal away from  
children.
- .4 Use sealers, form release and stripping  
agents that are non-toxic, biodegradable and  
have zero or low VOC's.

### PART 2 - PRODUCTS

#### 2.1 MATERIALS

- .1 Formwork materials:
  - .1 Use formwork materials to  
CAN/CSA-A23.1.
- .2 Form ties:
  - .1 Removable or snap-off metal ties, fixed  
or adjustable length, free of devices leaving  
holes larger than 25 mm diameter in concrete  
surface.

P/N: 711872/721941  
Wharf Reconstruction  
Musgrave Harbour, NL

- .3 Form release agent: non-toxic, chemically active release agents containing compounds that react with free lime present in concrete to provide water insoluble soaps, preventing set of film of concrete in contact with form.
- .4 Falsework materials: to CSA-S269.1.
  - .1 Materials required to bear grade marks, or be accompanied with certificates, test reports or other proof of conformity.
- .5 Premoulded joint fillers:
  - .1 Bituminous impregnated fibreboard to ASTM D1751.
- .6 Bond Breaker:
  - .1 Impermeable tube formed of polyvinylchloride, rubber or similar material to the approval of the Departmental Representative. Internal diameter equal to dowels.
- .7 Sealant: to Section 07 92 10 - Joint Sealing.

### PART 3 - EXECUTION

#### 3.1 FABRICATION AND ERECTION

- .1 Verify lines, levels and centres before proceeding with formwork/falsework and ensure dimensions agree with drawings.
- .2 Obtain Departmental Representative's approval for use of earth forms framing openings not indicated on drawings.
- .3 Hand trim sides and bottoms and remove loose earth from earth forms before placing concrete.
- .4 Fabricate and erect falsework in accordance with CSA S269.1.

P/N: 711872/721941  
Wharf Reconstruction  
Musgrave Harbour, NL

Page 4  
2018-02-02

---

- .5 Fabricate and erect formwork in accordance with CAN/CSA-S269.3 to produce finished concrete conforming to shape, dimensions, locations and levels indicated within tolerances required by CAN/CSA-A23.1.
- .6 Align form joints and make watertight. Keep form joints to minimum.
- .7 Use 25 mm chamfer strips on external corners and/or 25 mm fillets at interior corners, joints, unless specified otherwise.
- .8 Form chases, slots, openings, drips, recesses, expansion and control joints as indicated.
- .9 Build in anchors, sleeves, and other inserts required to accommodate Work specified in other sections. Assure that all anchors and inserts will not protrude beyond surfaces designated to receive applied finishes, including painting.
- .10 Clean formwork in accordance with CAN/CSA-A23.1, before placing concrete.

### 3.2 REMOVAL AND RESHORING

- .1 Leave formwork in place for following minimum periods of time after placing concrete.
  - .1 5 days for slabs, decks and other structural members, or 3 days when replaced immediately with adequate shoring to standard specified for falsework.
- .2 Remove formwork when concrete has reached 75% of its design strength or minimum period noted above, whichever comes later, and replace immediately with adequate reshoring.
- .3 Provide all necessary reshoring of members where early removal of forms may be required

P/N: 711872/721941  
Wharf Reconstruction  
Musgrave Harbour, NL

Page 5  
2018-02-02

---

or where members may be subjected to additional loads during construction as required.

- .4 Space reshoring in each principal direction at not more than 3000 mm apart.
- .5 Re-use formwork and falsework subject to requirements of CAN/CSA-A23.1.

### 3.3 JOINT FILLERS

- .1 Install joint filler in all joints.

### 3.4 JOINT SEALANT

- .1 Fill control joints with sealer as per manufacturer instructions. Sealant to be suitable for application in a seawater marine environment.