<u>NOTES:</u>

- 1. TRAIL DESIGN REFER TO DRAWINGS T-1 TO T-26.
- 2. BOTTOM OF INSIDE CULVERT TO BE FILLED WITH UNCOMPACTED NATIVE MATERIAL AS PER SECTION-A.
- 3. FOR AMPHIBIAN CULVERT LOCATIONS, REFER TO DRAWINGS D-1 & D-2.



